

OPERATOR'S SAFETY AND SERVICE MANUAL



R670

This manual covers the following for each model listed:

R670H serial number 23-0901-208 and higher



TRENCH RAMMER

MBW EUROPE LTD

Units 2&3 Cochrane Street
Bolton
Greater Manchester
BL3 6BN
Phone: (+44) 01204 387784
Email: sales@mbweurope.com
Website: mbweurope.com

© MBW Europe 2024
Printed in the UK

This page is intentionally left blank

Foreword

This manual has been written to help you operate the R670 Rammer safely. It is intended primarily for dealers and operators of equipment. It is recommended that you keep this manual or a copy of it with the machine so that it is readily available for reference.

Before you operate or carry out any maintenance on this machine YOU MUST READ and UNDERSTAND this manual.

Should you have ANY QUESTIONS about the safe use or maintenance of this machine after reading this manual, ASK YOUR SUPERVISOR or CONTACT:

MBW Europe on (+44) 01204 387784

MBW Europe reserves the right to change machine specification without prior notice or obligation.

Special Instructions



CAUTION

This CAUTION sign indicates a potential hazard, which if ignored, could result in injuries to the operator and/or those close by, as well as damaging the machine.



WARNING

This WARNING sign indicates a potential hazard, which if ignored could result in the DEATH of the operator and/or those close by.

Contents

| | |
|----------------------------------|-------|
| Foreword | 3 |
| Safety Information | 4-6 |
| Environment | 6 |
| Machine Description..... | 7 |
| Pre-Start Checks | 8 |
| Start And Stop Procedure | 8-9 |
| Operation..... | 10 |
| Service and Maintenance..... | 10-11 |
| Transportation And Storage | 11-12 |
| Trouble Shooting..... | 13 |
| Technical Data | 13 |
| Spare Parts..... | 14-19 |
| Warranty..... | 20 |

Safety Information

For your own personal protection and for the safety of those around you, please read and ensure you fully understand the following safety information. It is the responsibility of the operator to ensure that he/she fully understands how to operate this equipment safely.



Improper maintenance can be hazardous. Read and understand this section before you perform any maintenance, service or repairs.

If you are unsure about the safe and correct use of the Rammer, consult your supervisor or Equipment.

General Safety

- This machine is heavy and must not be lifted single-handedly; either get help or use suitable lifting equipment.
- This machine is to be used for its intended application only.
- This machine must only be operated by well-trained personnel.
- The owner of this machine must observe, and train the user to observe, the effective laws of labour protection in the country of application.
- Personal Protective Equipment (PPE) must be worn by the operator whenever the equipment is being used.
- Cordon off the work area and keep members of the public and unauthorised personnel at a safe distance.
- This machine must be operated on ground where stability is guaranteed. When working near the rim of excavated trenches, use the machine properly so that the machine may not fall down or collapse the excavation.
- Make sure you know how to safely switch this machine OFF before you switch it ON in case you run into any difficulties.
- Always switch OFF the engine before servicing it.
- During use, the engine becomes very hot. Always allow the engine to cool down before touching it.
- Never leave the engine running and unattended.
- Never remove or tamper with any fitted guards; they are there for your own protection. If they are damaged or missing, DO NOT USE THE MACHINE until the guard has been replaced or repaired.
- Always switch OFF the engine before transporting it, moving it around site or servicing it.
- Do not operate the machine when you are ill, feeling tired or when under the influence of alcohol or drugs.
- This machine is designed to eliminate the possible risks arising from the use of it. However, risks DO reside, and these residual risks are not clearly recognisable and may cause personal injury or property damage, and possibly death. If such unpredictable and unrecognisable risks become

apparent, the machine must be stopped immediately, and operator or his supervisor must take appropriate measure to eliminate such risks. It is sometimes necessary that the manufacturer must be informed of such event for future counter measuring.

Fuel Safety



WARNING

Fuel is flammable. It may cause injury and property damage. Shut down the engine, extinguish all open flames and do not smoke while filling the fuel tank. Always wipe up any spilled fuel.

- Before re-fuelling, switch off the engine and allow it to cool.
- When re-fuelling, use a proper funnel, and avoid spilling over the engine.
- When re-fuelling, DO NOT smoke or allow naked flames in the area.
- Spilt fuel must be made safe immediately by using sand. If fuel is spilt on your clothes, change them.
- Store fuel in an approved, purpose made container away from heat and sources of ignition.

Health & Safety

Vibration

Some vibration from the compacting operation is transmitted through the handle to the operator's hands. Ensure operator rotation and do not exceed the maximum recommended usage times.

Dust

The compaction process can produce dust, which may be hazardous to your health. Always wear a mask that is suited to the type of dust being produced.

Fuel

Do not ingest fuel or inhale fuel vapors and avoid contact with your skin. Wash fuel splashes immediately. If you get fuel in your eyes, irrigate with copious amounts of water and seek medical attention as soon as possible.

Exhaust Fumes



WARNING

The exhaust fumes produced by this machine are highly toxic and can kill!

Do not operate the R670 Rammer indoors or in confined spaces. Make sure the work area is adequately ventilated.


Environment

In order to protect the environment please recycle any discarded apparatus or accessories. The table beside provides you with a list of the machine's components and their respective materials. Take the discarded apparatus to the relevant recycling facilities.



| Component | Material |
|------------------|---------------------|
| Handle | Steel |
| Ramming Shoe | Plywood and Steel |
| Rubber Isolators | Rubber and Steel |
| Bellow | Urethane |
| Crankcase | Aluminium |
| Crankcase Cover | Aluminium |
| Gears | Steel |
| Engine | Steel and Aluminium |
| Various Parts | Steel and Aluminium |

Machine Description



1. Oil Plug/Sight Glass
2. Engine
3. Throttle Lever
4. Operating Handle
5. Fuel Tank
6. Lifting Point
7. Three-Position throttle control (Idle, Full Speed, Engine Stop Switch/Fuel Valve Closed)
8. Primary Air Cleaner
9. Crankcase
10. Bellow
11. Ramming Shoe/Foot

Pre-Start Checks


Inspection prior to start-up

The following inspection must be performed before the start of each work session or after every four hours of use, whichever is first. Please consult the Service and Maintenance section for detailed guidance. If any fault is discovered, the machine must not be used until the fault is rectified.

1. Thoroughly inspect the machine for signs of damage.
2. Check hoses, filler openings, drain plugs and any other areas for signs of leakage. Fix any leaks before operating.
3. Check the engine oil level and top up as necessary.

3.1 Place the machine on a level surface and check the oil in the engine.

3.2 Use proper engine oil with the proper viscosity (SAE 10W-30 is recommended).



4. Check the engine fuel level and top up if required. Use clean fuel. Use of contaminated fuel may damage the fuel system.



CAUTION

This machine uses unleaded petrol

5. Check the air filter is clean. Excessive dirt/dust accumulation within the filter element will cause erratic engine operation. Clean the air filter if it is contaminated (see Service and Maintenance section).

Having carried out the check in the 'Pre-Start' section, you may now start the engine.

Start and Stop Procedure



CAUTION

Improper operation can be hazardous. Read and understand this section before you start the machine.

1. Open the fuel tap.
2. Set the engine switch to the ON position.
3. Set the speed control lever to the STARTING position (Halfway between HIGH and LOW position).
4. Move the choke lever to the CLOSED position.
5. Taking a firm hold of the Operating handle with one hand, grasp the recoil starter handle with the other, Pull the recoil starter handle until engine resistance is felt, then let starter return.
6. Taking care not to pull the starter rope fully out, pull the starter handle briskly.
7. Repeat until the engine fires.
8. Once the engine fires gradually set the choke lever to the OPEN position.
9. Let the engine run at idle for a few minutes to warm up.

10. After the engine has warmed up, the machine is ready for operation.
11. Move the throttle lever to the high speed position quickly to prevent damage from occurring to the clutch. The 'Full Throttle' position of this machine has been preset at the factory to achieve optimum machine performance.
12. With the engine running in the full throttle position, the machine will move forward and compact loose 'lifts'
13. In preparation for stopping the engine, move the throttle lever to the LOW position.
14. Allow the engine to idle for 1-3 minutes.
15. Set the engine switch to the OFF position. Do not touch the HOT engine part at this time.
16. Close the fuel tap.
17. Pull the recoil starter slowly until you feel resistance. Then release your hand from the starter knob to set it back to its original position. This will prevent any air or humidity from entering into the cylinder.

| Model | Engine | Maximum RPM | |
|-------------|---------------------|-------------|-------------|
| | | Optimum | Upper Limit |
| R670 | HONDA GXR120 | 3800 | 4000 |

The Max rpm as shown above is the number of ignitions per minute. GX120K1 engine for the R670 have the final gears at the ratio of 17/16, and the number of ignitions per minute is different from the number of rotations of the engines Power Take-Off Shaft.



DO NOT alter this setting since irregular vibration or damage to the gear transmission mechanism can result, and both engine and machine warranties will be automatically voided.

Operation

This machine is fitted with a centrifugal clutch. This allows the engine to run at idle without driving the power transmission gears. As the engine speed is increased, the clutch will engage and the engine will drive the power transmission gears. As the engine speed is increased, the clutch will engage and the engine will drive the power transmission gears.

- To avoid damage to the centrifugal clutch, move the throttle lever quickly from the slow to fast position. For correct operation, the engine speed should be set to maximum.
- Avoid operating the machine on a fully compacted, hard, or non-yielding surface. Otherwise, the power transmission gears will be damaged and the life of the machine will be greatly reduced.
- When working in a narrow trench, if the ramming shoe should get caught between the walls of the trenches, the rammer may miss-strike and can be severely damaged.
- Be sure that the rammer is steered only with the handle. It should only be pushed. The rammer must not be pressed into the materials being compacted. Excessive pressure on the operating handle will lead to the unsatisfactory compaction due to the fact that the jumping action is hindered.

Operation at High Altitude

For continuous High-Altitude operation above 1,000m (3,000FT), it will be necessary to change the engine main jet to a type that will allow for correct fueling of the engine. Otherwise, the unit will suffer from a lack of engine power and not work correctly. Please contact Equipment for details.

Service and Maintenance

The Rammers are designed to give many years of trouble free operation. It is, however, important that the simple regular maintenance listed in this section is carried out. It is recommended that an approved equipment dealer carry out all major maintenance and repairs. Always use genuine replacement parts.

Before any maintenance is carried out on the machine, switch off the engine and disconnect the HT lead from the spark plug. Always set the machine on level ground to ensure any fluid levels will be correctly read. Only use recommended oils.

Servicing the Engine

Service the engine according to the engine manufacturer's specifications. Refer to the engine operation and maintenance manual.

Maintenance: Every 8 hours or daily

1. Check for loose bolts and nuts, retighten if necessary.

2. Check and clean the air filter element, re-lube the element in accordance with the engine manufacturer's recommendations. If operating conditions are unusually dusty and severe, filter element cleaning should be done more frequently.

3. Check oil level in crankcase of engine and replenish as necessary. Check the oil level in the ramming cylinder according to the following procedures:

- Make sure that the machine has not been run in the last 10 minutes.
- Set the machine on a level surface and remove the oil plug.
- The top surface of the oil must be seen just below the lower rim of the hole on the oil sight glass. Replenish as necessary.

NOTICE: Care should be taken not to overfill the rammer with oil. Overfilling will cause excessive load on the engine, which may result in poor or irregular vibration.

Maintenance: Every 50 hours or weekly

Check for loose bolts and nuts. Retighten if necessary.

Maintenance: Every 200 hours

Check the ramming cylinder oil. Do not overfill.

Fuel, Lubricant

| Model | Fuel | | Engine Crankcase | | | Ramming Cylinder | |
|-------|-----------------|----------|---|--------|----------|---|----------|
| | Type | Capacity | Type | Engine | Capacity | Type | Capacity |
| R670 | Unleaded Petrol | 3.8L | SAE 10W – 30, API, SG, SF/CC, CD | GXR120 | 0.28L | SAE 10W – 30, API, SG, SF/CC, CD | 0.8L |

Transportation and Storage

Lifting

Where it is necessary to use lifting equipment to position the rammer, check and confirm that the rubber isolators on the operation handle is not damaged or cracked. If they are cracked or damaged, replace the rubber isolators before attempting to lift the machine. Also make sure that the lifting equipment has a WLL (Working Load Limit) suitable for the rammer's weight (see technical data on page 13). Attach suitable chains or slings **ONLY** to the lifting point on top of the rammer's operating handle.

- NEVER leave the engine running whilst transporting or moving the R670 Rammer, even if it is only a short distance.

On Site Transport

The rammer may be moved vertically by 2 people, or laid only on the Transport Rollers.

Road Transport

The rammer must be transported as far as possible standing up, strapped to the body side board of the truck, or strapped inside a lorry (panel truck). If not possible, it may be laid down (engine facing upwards, not on its sides) only on the Transport Rollers, in a stable position and strongly strapped down to guard against rolling or sliding.



Wait until the unit is completely cool before laying it down.


Long-term Storage

The chemical composition of the fuel will deteriorate after prolonged storage. When the machine needs to be stored for a long time, remove all the fuel from the fuel tank. You can achieve this by running the engine with the fuel tap being closed (see picture). Also remove the fuel from the drain plug.

Clean up oil and dust accumulation on rubber parts.

Clean the base plate and apply a light coating of oil to prevent rust formation.

Cover the machine and store in a dry place.




Trouble Shooting

| Problems | Possible Causes | Countermeasures |
|---|---|--|
| Engine will not start | <ol style="list-style-type: none"> 1. No fuel. 2. Fuel tap has been closed. 3. Engine turned off. 4. Contaminated/damaged spark plug. 5. Faulty carburetor | <ol style="list-style-type: none"> 1. Fill fuel tank. 2. Open fuel tap. 3. Turn engine ON. 4. Replace spark plug. 5. Service the carburetor. |
| Engine stops suddenly or stops when the engine rpm is increased | <ol style="list-style-type: none"> 1. See above 2. Main jet of the carburetor clogged with dirt. 3. Air filter element dirty. 4. Spark plug cap is loose | <ol style="list-style-type: none"> 1. See above. 2. Take out main jet of the carburetor and clean with an air gun. 3. Clean the element. 4. Tightly fit cap to the plug. |
| Engine runs but unit does not produce impact | <ol style="list-style-type: none"> 1. Lack of engine power. 2. Clutch is slipping. 3. Power transmission gears are damaged. | <ol style="list-style-type: none"> 1. See above 2. Dismantle clutch assembly, clean shoe and drum with proper solvent. Replace clutch shoe if necessary. 3. Contact dealer. |


Technical Data

| MODEL | R670H |
|---|---|
| DIMENSION (LxWxH) - mm (in) | 775x360x1,062 (30.5x14.2x42) |
| OPERATING WEIGHT - KG | 67 |
| SHOE SIZE (LxW) - mm (in) | 340X285 (13.4x11.2) |
| STROKE - mm (in) | 80 (3.2) |
| IMPACT FORCE - KG (lb) | 1,580 (3485) |
| BLOWS PER MINUTE (bpm) | 650 -700 |
| COMPACTION DEPTH (DEPENDING ON SOIL) - cm (in) | 61 (24) |
| TRAVEL SPEED - m/min (ft/m) | 8-11 (26-36) |
| COMPACTED AREA - m ² /h (ft ² /h) | 300 (3,229) |
| FUEL TANK CAPACITY- Ltr (gal) | 3.5 (0.92) |
| ENGINE | HONDA GXR120 |
| ENGINE TYPE | Air-cooled single-cylinder 4- stroke Gasoline Engine |
| POWER OUTPUT - hp (Kw) | 3.6 (2.7) / 3600RPM |




Fuel Tank & Handle Assembly

| Item | Part no. | Description | Qty. |
|------|-----------------------------|-----------------------|------|
| 1 | R670H-70B-010112E | FUEL TANK CAP | 1 |
| 2 | R670H-70B-010120 | STRAINER | 1 |
| 3 | R670H-70C-010200 | FUEL TANK | 1 |
| 4 | R670H-70ND-010115 | PACKING | 1 |
| 5 | R670H-70C-010700 | FUEL TANK CAP, BOTTOM | 1 |
| 6 | R670H-70B-000021 | HOSE BAND | 2 |
| 7 | R670H-70C-010500 | FUEL HOSE | 1 |
| 8 | R670H-010100C | HANDLE | 1 |
| 9 | R670H-FN.W8-DIN-1 | WASHER | 3 |
| 10 | R670H-HSPG.W8-DIN-1 | SPRING WASHER | 4 |
| 11 | R670H-HS.B-M8x16-8.8-GB-1 | SCREW | 3 |
| 12 | R670H-FN.B-M8x20-8.8-DIN-1 | BOLT | 1 |
| 13 | R670H-FN.B-M10x25-8.8-DIN-1 | BOLT | 4 |
| 14 | R670H-HSPG.W10-DIN-1 | SPRING WASHER | 4 |
| 15 | R670H-HF.B-M5x20-8.8-DIN-3 | HEXAGON FLANGE BOLT | 4 |
| 16 | R670H-65ND-010100 | ROLLER | 2 |
| 17 | R670H-HF.N-M5-DIN-3 | HEXAGON FLANGE NUT | 4 |
| 18 | R670H-FN.B-M6x20-8.8-DIN-1 | BOLT | 2 |
| 19 | R670H-70C-010300 | THROTTLE LEVER ASSY | 1 |
| 20 | R670H-HSPG.W6-DIN-1 | SPRING WASHER | 6 |
| 21 | R670H-FN.N-M6-DIN-1 | WASHER | 2 |
| 22 | R670H-012400 | LIMITED BLOCK | 2 |
| 23 | R670H-HSPG.W6-DIN-1 | SCREW | 4 |
| 24 | R670H-W06-S04-L670x780 | THROTTLE CABLE | 1 |
| 25 | R670H-20A-020208 | HOUR METER | 1 |
| 26 | R670H-FN.B-M6x16-8.8-DIN-1 | BOLT | 4 |
| 27 | R670H-014000 | COVER | 1 |
| 28 | R670H-HSPG.W6-DIN-1 | SPRING WASHER | 4 |
| 29 | R670H-014001 | SPACER | 2 |
| 30 | R670H-IN.N-M6-DIN-2 | LOCK NUT | 2 |
| 31 | R670H-HF.B-M6X30-8.8-DIN-2 | HEXAGON FLANGE BOLT | 2 |



Gear Case & Engine Assembly

| Item | Part no. | Description | Qty. |
|------|--|-------------------------|-------|
| 1 | R670H-W05-GXR120 | ENGINE | 1 |
| 2 | R670H-021500 | PIN | 2 |
| 3 | R670H-WKey-4x5x13 | WOODRUFF KEY | 1 |
| 4 | R670H-W18-C812A | CENTRIFUGAL CLUTCH ASSY | 1 |
| 5 | R670H-80-0998 | LOCK WASHER | 1 |
| 6 | R670H-FNL.N-M12x1.25-DIN-2 | THIN NUT | 1 |
| 7 | R670H-020700 | BOLT | 4 |
| 8 | R670H-HF.N-M8-DIN-2 | HEXAGON FLANGE NUT | 4 |
| 9 | R670H-020500H | SUPPORT BASE, ENGINE | 1 |
| 10 | R670H-PEM NUT-M8 | RIVET NUT | 4 |
| 11 | R670H-FN.W8-DIN-1 | WASHER | 4 |
| 12 | R670H-HSPG.W8-DIN-1 | SPRING WASHER | 4 |
| 13 | R670H-HS.B-M8x20-8.8-GB-1 | SCREW | 4 |
| 14 | R670H-020300 | PINION | 1 |
| 15 | R670H-W03-62×40×11TCN | OIL SEAL | 1 |
| 16 | R670H-CH.RG55 | INTERNAL CIRCLIP | 1 |
| 17 | R670H-W01-6907-J | BEARING | 2 |
| 18 | R670H-CS.RG35 | EXTERNAL CIRCLIP | 2 |
| 19 | R670H-025000 | GEAR CASE | 1 |
| 20 | R670H-70B-020101 | WASHER | 1 |
| 21 | R670H-W01-TAF324220 R670H-W01-LRT283220 | BEARING | 1 SET |
| 22 | R670H-70B-020112 | SCREW | 1 |
| 23 | R670H-W01-6207-J | BEARING | 1 |
| 24 | R670H-CH.RG72 | INTERNAL CIRCLIP | 1 |
| 25 | R670H-70C-020115 | CRANK GEAR | 1 |
| 26 | R670H-CS.RG20 | EXTERNAL CIRCLIP | 1 |
| 27 | R670H-020400 | PACKING, FRONT COVER | 1 |
| 28 | R670H-021200 | FRONT COVER | 1 |
| 29 | R670H-FN.W8-DIN-1 | WASHER | 8 |
| 30 | R670H-HSPG.W8-DIN-1 | SPRING WASHER | 8 |
| 31 | R670H-HS.B-M8x25-12.9-GB-3 | SCREW | 8 |
| 32 | R670H-020100 | HANDLE SUPPORT | 1 |
| 33 | R670H-70B-020125A | SHOCK MOUNT | 2 |
| 34 | R670H-FN.W10-DIN-1 | WASHER | 4 |
| 35 | R670H-HSPG.W10-DIN-1 | SPRING WASHER | 4 |
| 36 | R670H-HS.B-M10x20-8.8-GB-1 | SCREW | 4 |
| 37 | R670H-HF.B-M10x20-8.8-GB-1 | FLANGE BOLT | 4 |
| 38 | R670H-022100 | AIR FILTER BOX | 1 |
| 39 | R670H-60ND-000011 | CLIP | 2 |
| 40 | R670H-023200 | INTAKE PIPE | 1 |
| 41 | R670H-HF.B-M8x20-8.8-GB-1 | FLANGE BOLT | 12 |
| 42 | R670H-022500 | DUST CAP | 1 |
| 43 | R670H-022400 | FAN | 1 |
| 44 | R670H-022600 | AIR FILTER | 1 |
| 45 | R670H-022200 | FILTER BOX COVER | 1 |
| 46 | R670H-022300 | SCREW | 1 |
| 47 | R670H-012300 | SHOULDER BOLT | 2 |
| 48 | R670H-012200 | BUSH | 2 |
| 49 | R670H-IN.N-M10-DIN-2 | LOCK NUT | 2 |
| 50 | R670H-020900R | COVER-RIGHT | 1 |
| 51 | R670H-020900L | COVER-LEFT | 1 |
| 52 | R670H-CGS250-021100 | CLIP | 1 |
| 53 | R670H-HS.B-M6x16-8.8-GB-1 | SCREW | 1 |



Guide Cylinder & Spring Assembly

| Item | Part no. | Description | Qty. |
|------|----------------------------|-----------------------------------|------|
| 1 | R670H-030600 | CONNECTING ROD | 1 |
| 2 | R670H-W01-6304-J | BEARING | 1 |
| 3 | R670H-CH.RG52 | INTERNAL CIRCLIP | 1 |
| 4 | R670H-030650 | BUSH | 2 |
| 5 | R670H-030700 | OUTER SPRING | 2 |
| 6 | R670H-CH.RG16 | INTERNAL CIRCLIP | 2 |
| 7 | R670H-030400 | PISTON PIN | 1 |
| 8 | R670H-030300 | PISTON | 1 |
| 9 | R670H-030250 | BUSH | 2 |
| 10 | R670H-70ND-020218 | PACKING | 1 |
| 11 | R670H-030200 | SPRING CYLINDER | 1 |
| 12 | R670H-W04-88x3.5 | O RING | 1 |
| 13 | R670H-50ND-030013 | BELLOW CLAMP | 2 |
| 14 | R670H-50ND-030016P | BELLOW | 1 |
| 15 | R670H-030100 | SPRING HOUSING | 1 |
| 16 | R670H-GB97.1-M14 | WASHER | 2 |
| 17 | R670H-HHOS.B-M14x1.5 | HEXAGON HEAD PLUG | 2 |
| 18 | R670H-ZH-D-M20 | WASHER | 1 |
| 19 | R670H-100GB-041000 | OIL GAUGE | 1 |
| 20 | R670H-W04-94.4x3.1 | O RING | 1 |
| 21 | R670H-70C-030200 | FOOT PLATE | 1 |
| 22 | R670H-HSPG.W10-DIN-1 | SPRING WASHER | 8 |
| 23 | R670H-HS.B-M10x25-8.8-GB-1 | SCREW | 4 |
| 24 | R670H-FN.W10-DIN-1 | WASHER | 8 |
| 25 | R670H-HS.B-M10x35-8.8-GB-1 | SCREW | 4 |
| 26 | R670H-04-175MM | REPLACEMENT SHOE ASSY 7" / 175MM | 1 |
| | R670H-04-230MM | REPLACEMENT SHOE ASSY 9" / 230MM | 1 |
| | R670H-04-280MM | REPLACEMENT SHOE ASSY 11" / 280MM | 1 |

WARRANTY

1. IN GENERAL - The warranties described in this document are provided by MBW EUROPE, LTD. ("MBW") to define what is, what is not, and for how long machines and parts are covered against material defects and/or defective workmanship. To obtain warranty service, the purchaser must, within the Warranty Period (defined in Paragraph 3): (i) report the product defect to an authorised repair center, (ii) make a written request for repair, (iii) provide proof of purchase to the authorised repair center, and (iv) deliver the equipment to the authorised repair centre. A list of authorised repair centres is available on the MBW website (mbweurope.com) or by contacting MBW at (+44) 01204 387784

2. COVERED - MBW's obligation under this limited warranty is limited to the cost of the parts and the labor to repair any defect in material and/or workmanship at an authorised MBW repair center. Transportation charges are not covered by this limited warranty.

3. WARRANTY PERIODS - The Warranty Period begins on, as applicable: (i) the product purchase date by an end user or (ii) the first day the product is put into rental or two years after invoice date from MBW to Dealer, whichever starts the warranty period first. To insure that your warranty is in place, fill out the warranty card and mail it in or register your product online at www.mbw.com/service-support/warranty-registration. The warranty is nontransferable.

The Warranty Period ends after:

- A. New Ground compaction equipment - 2 years.
- B. New Concrete finishing equipment - 1 year.
- C. New Utility equipment - 1 year.
- D. Demonstration equipment - 6 months.
- E. Wear parts: lubricants, filters, belts and shock mounts - 30 days.

4. NOT COVERED - This warranty does not include, and MBW specifically excluded from any warranty:

- A. Used equipment - all used equipment is not warranted and is sold 'as is' 'where is' with all defects.
- B. Replacement electrical parts, including but not limited to: electric motors, circuit boards, switches, are not warranted or returnable.
- C. OEM: engines, batteries, and chargers. Those warranties are covered by the manufacturer.
- D. Consumable parts: trowel and screed blades.
- E. Equipment that has been: altered, abused, neglected, not maintained, or modified to run outside its specifications. Any modification to the machine or its parts makes this warranty null and void.
- F. Other: damage to a product from normal wear, air freight, overtime, pickup and delivery, temporary replacement rentals, freight damage, or other similar incidents.
- G. Product used in a fashion it was not designed for.
- H. Parts and labor not performed by authorised dealers.

It is at MBW's discretion if warranty applies and has the right to adjust labor rates on a claim by claim basis.

5. OTHER - IT IS EXPRESSLY AGREED THAT THIS SHALL BE THE SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY. UNDER NO CIRCUMSTANCES SHALL MBW BE LIABLE FOR ANY COSTS, LOSS, EXPENSE, DAMAGE, SPECIAL DAMAGES, DIRECT DAMAGES, INCIDENTAL DAMAGES, EXEMPLARY, CONSEQUENTIAL, OR PUNITIVE DAMAGES ARISING DIRECTLY OR INDIRECTLY FROM THE USE OF MBW PRODUCT OR DAMAGES FOR LOSS OF USE, LOSS OF ANTICIPATED PROFITS, INCOME, OR ECONOMIC LOSSES OF ANY KIND. MBW'S LIABILITY TO BUYER UNDER THESE WARRANTIES FOR THE PRODUCT IS LIMITED AS SET FORTH HEREIN, WHETHER BASED UPON WARRANTY, CONTRACT, NEGLIGENCE, TORT, STRICT LIABILITY OR ANY OTHER THEORY OF LIABILITY, INCLUDING BUT NOT LIMITED TO FRAUD, MISREPRESENTATION, BREACH OF CONTRACT, PERSONAL INJURY, PRODUCTS LIABILITY OR ANY OTHER THEORY.

MBW'S LIABILITY UNDER ANY WARRANTY HEREUNDER, WHETHER EXPRESS OR IMPLIED, SHALL NOT EXCEED THE COST OF REPAIR OR REPLACEMENT OF DEFECTIVE PARTS OF THE PRODUCT OR THE PRODUCT. BUYER MAY NOT BRING ANY ACTION UNDER THESE WARRANTIES MORE THAN ONE YEAR AFTER THE CAUSE OF ACTION HAS ACCRUED.

THE FORGOING WARRANTY IS EXPRESSED IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR USE, AND FITNESS FOR A PARTICULAR PURPOSE, AND ALL OTHER OBLIGATIONS OR LIABILITY ON MBW'S PART. MBW SPECIFICALLY DISCLAIMS AND EXCLUDES ANY AND ALL WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

MBW NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME ON BEHALF OF MBW ANY OTHER LIABILITY OR WARRANTY IN CONNECTION WITH THE SALE OR SERVICE OF ANY MBW PRODUCT.

Some countries do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from country to country.